



## Fire Alarm Systems Web-Server II

1598

### Features

- Web-Server II, 1598; second Web-Server generation
- Increased memory and faster CPU
- The same hardware can be used for the functions Web512, Web128 or OPC512

### General

Web-Server II has a plastic cabinet, which is vertically mounted on a symmetric 35 mm DIN rail. Web-Server shall be mounted inside FT512 or FT128 cabinets. A cable and accessories kit for both systems is supplied with the Web-Server II.

### Web-Server II Software

Depending on the downloaded software, the web-server II can be used for the functions **Web512**, **Web128** or **OPC512**. A configuration tool is used to create and download the configuration and the software for the function respectively to the Web-Server II.

### Web512/Web128

#### Web512 II Configuration tool.

#### Web128 II Configuration tool.

For presentation of the actual FT512 (version > 2.3) or FT128 (version > 1.0) status in a PC using the web browser Microsoft Internet Explorer, via Internet or an intranet (LAN). *User name* and *Password* can be used. For FT512, version > 2.5 or FT128 version > 1.1, also remote control with encrypted and safe two-way communication. *User names* and *Passwords* for five different *User (access) levels*. emails can be sent in case of fire alarm, pre-warning, test mode alarm, fault, disablement and/or service signal. One of the following gateway functions can be used:

*FT Talk*

*Tateco*

*SIA (FT512 only.)*

### OPC512

#### OPC512 II Configuration tool.

FT512 version > 2.5 can via the Web-Server II, be connected to a PC with Panasonic FP OPC Server, which allows high-performance data transfer between industrial applications (clients) supporting the universally accepted OPC DA Standard (v1-v3) and Panasonic FP Series PLCs.

### Interfaces

Web-Server II has the following interfaces:  
**PLC COM. (RS232C)** RS232C (without handshake), for connection of Web-Server II to an FT c.i.e. One RS232 connection cable is supplied for connection to the Web-Server II plug-in screw terminal block (**Send – Receive – Ground**).

**Modem COM. (RS232C)** For connection of Web-server II to a modem or a separate PC system. One 9 ways male "D" connector, compatible to an IBM PC serial port. (The cable is not supplied.)

**Ethernet COM. (10 BASE-T)** For connection of Web-Server II to Internet / an intranet (LAN). One RJ45 connector for a standard Ethernet cable (e.g. CAT.5). (The Ethernet cable is not supplied.)

**Power supply** For connection of Web-Server II to 24 V DC (i.e. to an FT c.i.e. or an external equipment). A power cable for each system is supplied and shall be connected according to the supplied Installation Detail.

## Type numbers


1598	Web-Server II, incl. cable & accessories kit (the RS232C and power supply Cables for system FT512 are 3m and for system FT128, 0.65m).
------	--

### NOTE!

The configuration tool is different depending on the system (FT512 or FT128), the **firetracker** software version and also the function. It is very important that the configuration tool has the same version as the **firetracker** version, i.e. the first two digits (e.g. 2.5.x).

## Product Applications

Web-Server II 1598 is intended for indoor use and in dry premises. It can be used in systems FT512 and FT128 for c.i.e. status presentation. In system FT512, version > 2.5 also for remote control. In system FT512, version > 2.5 the web-server II can, as an alternative, be an interface to a Panasonic FP OPC Server.



## Technical data

Voltage (V DC)	24
rated allowed	10.8-26.4
nominal	24
Current consumption at nom. volt. from COM loop (mA)	60
quiescent / active	65
Ambient temperature (°C)	0 to +55
operating / storage	-20 to +70
Ambient humidity (% RH)	Max. 85, non condensing
Ingress Protection rating	IP20
90	290
Size H x W x D (mm) Web-Server Only	90 x 25 x 69.5
Construction / Colour Web-Server	ABS plastic/light grey
Approvals	CE

*All technical features and data are subject to changes without notice, resulting from continuous development and improvement.*

**National Call: 1300 783 473**

Head Office: 4 Pike Street, Rydalmere NSW 2116 Tel: 02 9684 1466. Fax: 02 9684 4146.

All technical features and data are subject to changes without notice, resulting from continuous development and improvement.

Product Leaflet	Date of issue	Revision / Date of revision
Web-Server II 1598	05/02/2009	REV 2