



EIB208W

Carbon Monoxide Alarm

10 Year Non-removable Lithium Battery

The EIB208W is a carbon monoxide (CO) alarm with a powered-for-life sealed lithium battery. The alarm has a high performance, proven electrochemical sensor to sense CO presence. The sensor is individually calibrated and tested in CO gas to ensure accuracy.

With the option to fit a RadioLINK+ EI200MRF module to facilitate wireless connectivity, interconnected alarms will all sound if CO is detected by any alarm.

Features built-in AudioLINK+ technology for acoustic alarm data and status downloads via the AudioLINK+ app.

KEY FEATURES

- Proven electrochemical 10-year CO sensor
- Built in AudioLINK+ data extraction technology
- Wirelessly interconnect up to 12 devices via optional RadioLINK+ EI200MRF module
- Pre-alarm indication gives early warning of CO

COMPATIBILITY

Wireless: When fitted with the EI200MRF - EIB100MRF, EIB168RC, EIB170RFAU, EIB171RFAU, EIB3000MRF, EIB407RF, EIB408RF, EIB408RFH, EIB411RF, EIB413, EIB420RF, EIB428RF, EIB450, EIB600MRF, EIB605MRF and any alarm fitted with the RF module.

Note: for full specifications and limitations, refer to the specific product data sheet.

SPECIFICATION

Sensor Type	Electrochemical CO level is checked every 4 seconds
Supply Voltage	10 year life sealed lithium cell battery
Sound Level	85 dB(A) at 3m. Modulated sound gives 3 rapid pulses followed by a 1/2 second pause.
Button Test	Checks sensor, electronics & horn
Incidator LED's	Green - Power up / Red - Alarm / Yellow - Fault
Fixing	Screw fixing (supplied) & free standing
Temperature Range	Range -10°C to 40°C ¹ Storage -0 to 35oC (in a dry area)
Humidity Range	15% to 95% non-condensing
Dimensions	120mm x 105mm x 50mm
Weight	169g (Pack +38g)
Warranty	5 year (limited) warranty
Approvals	CO: BS EN 50291-1:2018 BS EN 50291-2:2019 KM 86596

¹ Temperature and Humidity conditions are for normal operation and storage. Units will function outside these ranges as required by the specific product Standards. Extended exposure to conditions outside these ranges can reduce product life. For advice on prolonged operation outside these ranges consult the manufacturer.



Manufactured to ISO 9001 quality standards

Brooks Australia Pty | 4 Pike Street, Rydalmere NSW 2116 Australia | 1300 783 473

E&OE As our policy is one of continuous product development, we reserve the right to alter product details without prior notice.