

EIB170RFAU - The Deaf & Hard of Hearing Kit

Key Features

- ▶ Flashing strobe light
- ▶ Plug-in vibration pad
- ▶ Wireless interconnection to RadioLINK units
- ▶ Visual RF transmission and power indicators
- ▶ Unique house-coding
- ▶ Easy to use test button
- ▶ Mains powered with rechargeable NiMH back-up battery
- ▶ 5 Year Guarantee (limited)



Product Description

The EIB170RFAU is a RadioLINK Alarm system designed to give warning to the deaf and hard of hearing on receipt of an alarm or test signal. The kit consists of a control box with integral strobe and a plug-in vibration.

The EIB170RFAU is designed to be powered from a permanent mains power supply. It also contains a rechargeable battery that provides back-up power in the event of mains failure.

Compatibility

- Mains Power:** 140RC Series with EIB168RC
160e Series with EIB100MRF
3000 Series with EIB3000MRF
- Ancillary Devices:** EIB407RF, EIB408RF, EIB408RFH,
EIB411RF, EIB413, EIB420, EIB428RF,
EIB450
- Battery Operated:** EIB600 series with EIB600MRF
EIB603C & EIB605C with EIB605MRF
- Note:** For full specification, and limitation for use, refer to the specific product data sheet

Technical Specification

- Supply Voltage:** 230
- Battery:** NiMH rechargeable
- RF Range:** >100m in free air
- Wireless:** RadioLINK 926 MHz
(up to 12 interconnected RadioLINK devices)
- Button Test:** Tests strobe, vibration pad, panel and all connected RadioLINK devices
- Alarm Indicators:** Flashing strobe light, Red LED flashes, vibration pad has an on-off 2 second cycle.
- Indicators LED's:** Power-up - Green
Alarm - Red
Fault - Amber
Test - Blue
- Fixing:** Wall mounting screw fixings supplied
- Temperature:** -10 to 40°C
- Humidity Range:** 15% to 95% non condensing
- Normal Operating and Storage Humidity Range:** 15% to 95% Relative Humidity (Non-condensing)
- Plastic material:** UL94VO flame retardant
- Weight:** 0.576kg
- Warranty:** 5 year (limited) warranty
- Approvals:** AS/NZS 60950.1:2015
AS/NZS 4268:2017



Due to continual product development, Brooks reserve the right to alter product details and specifications without prior notice.

Head Office: Sydney, 4 Pike Street, Rydalmere 2116 | PO Box 7050 Silverwater BC1811
Regional Offices: Melbourne - Brisbane - Adelaide - Perth - Auckland
www.brooks.com.au - Toll Free 1300 783 473