



Fire Products & Solutions

Mains Base

BR240V	Mains Base Red 240V for Brooks Strobes & Sounders
BW240V	Mains Base White 240V for Brooks Strobes & Sounders



The Mains Deep Base incorporates a small 24Vdc supply that allows any of the compatible sounders and strobes to be operated from 110 or 230Vac supplies. This allows the installer much greater flexibility in the use of products and their applications.

Features

- Wide input voltage range
- Up to 100mA output
- Suitable for external use

Technical Specification

Input voltage	110-240VAC 50-60Hz
Output voltage	24VDC
Output current	100mA max
Temperature	-20°C to +55°C
Monitoring	n/a
IP Rating	IP65
Construction	FR ABS (deep base)
Weight	0.1kg
Colour	Red or white

Compatible Devices

BS1060X	Brooks Strobe
MRCS	Roshni /Sounder
MFRSX	Flashni Sounder/ Strobe