

EIB164e - Heat Alarm

Mains Powered 230V~
Rechargeable Battery Back-up

Key Features

- Remote Test + Control – Wired & Wireless
- Integrated Piezo-electrical sounder
- Easi-fit base
- Test/Silence button
- Memory
- Low battery indication
- Hardwire interconnect
- Wireless interconnect when fitted with EIB100MRF RadioLINK⁺ module
- 5 year guarantee

Product Description

The EIB164e is a Heat Alarm with 230V AC mains power supply and rechargeable lithium battery back-up.

The EIB164e is supplied with the Easi-fit base to facilitate quick and simple installation, combined with easy detector head removal and replacement. The Easi-fit base automatically connects both mains power and battery as the detector head slides on.

The EIB164e may operate as a standalone alarm or may be interconnected to other alarms via a wired or wireless system. For RadioLINK⁺ interconnection simply plug in the optional RadioLINK⁺ module, saving time, mess and disruption in running interconnect cabling.

The alarm is fitted with a test / silence button to facilitate frequent testing of your alarm and system. The silence function allows the alarm / system to be silenced in the case of a false / nuisance alarm, e.g. cooking fumes.

The EIB164e is fitted with a mains "power on" green LED indicator and yellow LED indicator for fault conditions.

The memory feature allows an alarm that has previously activated to be easily identified.

Note: Heat Alarms must never replace required Smoke Alarms.



Technical Specification

Sensor Type:	Thermistor - activates at 58°C
Supply Voltage:	230V AC, 50Hz
Battery back-up:	10-year rechargeable Lithium battery
Sound Level:	85 dB(A) at 3 meters
Temperature:	Operating - 0 to 40°C Storage - 0 to 35°C (in a dry area)
Humidity Range:	15% to 95% RH (Non condensing)
Interconnect:	Hardwire or wireless interconnect (up to 12 devices)
Button Test:	Simulates a high temperature to check the Thermistor, electronics and horn
Insect Screen:	Prevents insects or debris entering chamber (1.00mm mesh size)
Plastic material:	UL94VO flame retardant
Dimensions:	Product - 148mm x 63mm Package - 153mm x 153mm x 68mm
Weight:	308g (Pack +73g)
Warranty:	5 year (limited) warranty
Approvals:	



Specifications are subject to change

Compatibility

Hardwire: BA128, EIB128RBU, BAVISA240, BAALOC and BAAISO / BAATLS (EIBPLATE must be used), EIB3000 Series, EIB160e Series, EIB140RC Series.

Wireless: EIB450, EIB411RF, EIB413, EIB170RFAU, EIB408RF, EIB408RFH, EIB428RF, EIB407RF, EIB168RC, EIB3000MRF.

Note: For full specification and limitation of use refer to the specific product data sheet

Due to continual product development, Brooks reserve the right to alter product details and specifications without prior notice.

Head Office: Sydney, 4 Pike Street, Rydalmere 2116 | PO Box 7050 Silverwater BC1811

Regional Offices: Melbourne - Brisbane - Adelaide - Perth - Auckland

www.brooks.com.au - Toll Free 1300 783 473