



Fire Products & Solutions

Addressable I/O Module with Isolator 4461



Product Description

The addressable generic I/O unit 4461 is a programmable inputs / outputs COM loop module with built-in short circuit isolator. Connection of 4461 is via the screw terminals as shown in Figure 2 page 4. All inputs and outputs are programmable via EBLWin.

The 4461 is fully functional when configured with FT1020G3 and FT128 for software \geq V2.4. For software $<$ V2.4 or to use in FT512, 4461 can be configured as a 3361 i.e. backward compatible, refer to the systems compatibility shown in Table 1, page 3. Red LED is provided in 4461 to illuminate when the function “Toggle LED” is selected in EBLWin.

Note: currently, when “4461 for fan” is programmed as “3361 for fan”, the fan status input In0 will not be supervised.

The unit is intended to be surface mounted and for indoor use. The 4461 can also be mounted inside a metal enclosure to meet specific requirements.

4461 provides two generic programmable relay outputs and three programmable inputs. Two of the inputs can be supervised and one is non-supervised. The programmable relay can be used in many applications e.g. zone line input, fan / damper control, MDH control, fire trips, any programmable relay contacts output, etc.

4461 Outputs

- Relay output **RE0**: programmed in EBLWin as any output type, either NC or NO contacts
- Relay output **RE1**: Programmed in EBLWin as any output type, either NC or NO contacts

4461 Inputs

1. Supervised Input Z/IN0

The supervised input **Z/IN0** can be configured with the following two options:

- **Zone line input (Z)**

This input is intended to be used as a conventional zone line input, EOL capacitor 10 μ F to be mounted in the last unit on the circuit as shown in Figure 1 page 2. Short circuit either activate a fault or fire alarm depending on programming in EBLWin. The state of the zone line input is dependent on the measured resistance as shown in the following threshold levels table below:

Normal Condition	Current \leq 1.5mA
High current fault	Current $>$ 2mA@18V
Alarm (normal condition)	100 Ω $<$ R $<$ 2.0 k Ω
Alarm (if short circuit is detected as alarm)	R $<$ 2.0 k Ω
Short circuit fault (if short circuit alarm is not selected)	R \leq 50 Ω
Open circuit fault	R \geq 250 Ω (approx.)

			Title		Technical Datasheet		 Fire Products & Solutions	
			Addressable I/O Module with Isolator 4461		Created	Checked	TDS No.	Rev
					A.S.	Engineering	TDS070	0
Date	Rev	Description	Page 1 of 4					
2/12/2020	0	Original Issue	2/12/2020	2/12/2020				

Note: Only 5 activated zone interfaces are allowed for each COM loop, limited by EBLWin.

- **General input (IN0)**

Voltage free contact input, either N/O or N/C. The state of the general input is dependent on the measured threshold level resistance for both supervised or non-supervised options as shown in the following table:

Line resistance R (values $\pm 10\%$)	Supervised		Not Supervised	
	N/O	N/C	N/O	N/C
$R > 43 \text{ k}\Omega$	Fault	N/A		Activated
$43 \text{ k}\Omega \geq R > 10 \text{ k}\Omega$ (nom. $33\text{k}\Omega$)	Not activated	N/A	Not activated	Activated
$R \leq 10 \text{ k}\Omega$	Activated	N/A	Activated	Not activated

2. Isolated Input IN1

The isolated input is an opto-coupler input, activates when an external 6-30 Vdc is applied, it requires 8mA.

3. General Input IN2

Voltage free contact input, either N/O or N/C. **IN2** Can be supervised if selected in EBLWin. Normally used to indicate phase fault when 4461 is configured as “4461 for fan/damper”.

Note: The general input **IN2** will not be in use when 4461 is configured as 3361.

Application Examples

Figure 1 below shows different wiring options for connecting 4461




Figure 1 Wiring options for 4461

1. **Supervised input Z/IN0 used as zone line input** – For connection of conventional detectors, manual call points or fan status input when 4461 used as “4461 for fan/damper”.
 - a) Detector with a closing contact and an alarm resistor e.g. sprinkler flow switch input.
 - b) Closing contact input e.g. flow switch. It can be programmed to “Alarm at short circuit”. Short circuit on the zone line input will then activate a fire alarm instead of a fault. End of line capacitor $10 \mu\text{F}$.
 - c) Fan/damper module, has been added to EBLWin software $\geq \text{V2.4.1}$. 4461 has the same functionality as the discontinued I/O unit 3361 without general IN2 and short circuit isolator.
2. **Supervised input Z/IN0 used as type general input**, the input has to be programmed with a trigger condition and to be normally open (N/O) or normally closed (N/C). EOL $33 \text{ k}\Omega$ resistor must be used if the

			Title		Technical Datasheet			
			Addressable I/O Module with Isolator 4461		Created	Checked	TDS No.	Rev
2/12/2020	0	Original Issue			A.S.	Engineering	TDS070	0
Date	Rev	Description			2/12/2020	2/12/2020		

general input is configured in EBLWin as supervised. Supervision is not applicable when the input is (N/C).

3. **Isolated input IN1**, the input has to be programmed with a trigger condition and to be normally high (+24V) or normally low (0V). The input is isolated and requires external 24VDC supply.
4. **General input IN2**, the input has to be programmed with a trigger condition and to be normally open (N/O) or normally closed (N/C). EOL 33 kΩ resistor must be used if the general input is configured as supervised in EBLWin. Supervision is applicable for only (N/O).

For each output, a control expression has to be programmed and if the relay contacts selected to be Normally Open (N/O) or Normally Closed (N/C).

Short Circuit Isolator

The 4461 has a built-in short circuit isolator that requires no separate COM loop address. Same as any other short circuit isolator, it will be given an individual sequence number, either when programmed in EBLWin or via automatic addressing or check loop function.

For FT1020G3 systems with software version \leq V2.2.x, the isolators must be connected consecutively regarding sequence number 00-64, in the COM loop's A-direction.

For FT1020G3 systems with software version \geq V2.4.X, the sequence numbers 00-127 can automatically be generated and sorted consecutively in the COM loop's A-direction. Function "Arrange sequence numbers" in EBLWin must be activated. (Tools/Options/EBLWin Settings).

For more information on short circuit isolators, see the FT128 or FT1020G3 Operation or Technical Manual.

Technical Address Setting

The 4461 supports automatic addressing via EBLWin, refer to system manuals for more details.

If auto addressing is not used, the address can be set manually using the address setting tool 4414. Each COM loop unit must have a unique COM loop address (001-253).

Notes:

1. The COM loop address and mode settings must be performed before the unit is connected to the COM loop.
2. The EOL capacitor for the supervised input must be disconnected during address and mode setting.

Addressing Mode Setting

The mode is set with the Address Setting Tool (4414) based on the following compatibility table shown below.

Table 1 Compatibility of 4461

	Advanced mode	NORMAL mode
FT1020G3	$V \geq 2.4.x$	All versions
FT128	$V = 2.4.x$	All versions
FT512 Configured as 3361 in Normal mode	Not used	All versions
Isolator in use	Yes	No


Installation

Note: Terminal designated N.C. (Not Connected) is not used but it can be utilised as screen wire termination.

The 4461 can be mounted inside the FDCIE or remotely close to the external equipment. In some applications where fire rated cables required e.g. fan control, the 4461 will be mounted in a metal enclosure. Two metal enclosures available:

BAMFME: Field module metal enclosure, fits 2 x 4461 (330x240x70) mm

BAMFMS: Field module metal enclosure, fits 1 x 4461 (240x160x70) mm

			Title		Technical Datasheet			
			Addressable I/O Module with Isolator 4461		Created	Checked	TDS No.	Rev
2/12/2020	0	Original Issue			A.S.	Engineering	TDS070	0
Date	Rev	Description	2/12/2020	2/12/2020				





Figure 2 Loop connection and PCB designator

Specifications

Note: All current consumptions are valid at the nominal voltage and at 25 °C.

Voltage: Allowed	12-30Vdc (15-30V when the monitored input is used as zone line input)
Normal	24V DC
Current: Quiescent (incl. Z /In0) Active (incl. internal LED)	≤ 4.3 mA ≤ 15 mA
Monitored inputs used as zone line input: Min voltage (at 15V COM loop voltage) Max voltage Max current (maximum detector current consumption) Limitation (maximum short circuit current) Maximum conductor resistance Maximum conductor capacitance	DC 12V DC 30V 1.5 mA 10mA typical 50 Ω 50 nF
Isolated Input: Max voltage, active Min voltage, active Max voltage, inactive Min voltage, inactive	30VDC 6VDC 1VDC -30VDC
Relay outputs:	contact rating 2A@30Vdc
Address range	1-253
Address setting	Auto addressing (or with address setting tool)
Ambient Temperature: Operating Storage	-10 to +50° C -20 to +60° C
Ambient humidity	Maximum 95, % RH (Non condensing)
Enclosure	Standard Fibox. 110H x 110W x 49D mm
Material and IP rating	Polypropylene, IP 65
Approval	ISO/AS 7240.17 & ISO/AS 7240.18

			Title		Technical Datasheet			
			Addressable I/O Module with Isolator 4461					
			Page 4 of 4					
2/12/2020	0	Original Issue			Created	Checked	TDS No.	Rev
Date	Rev	Description			A.S.	Engineering	TDS070	0
					2/12/2020	2/12/2020		