

EIB411RF - Wireless Wall Mount Remote Control

With Test, Hush and Locate

Key Features

- Allows control of alarm system
- Designed for use with the EIB168RC RadioLINK base with an 'RC' series alarm and RadioLINK smoke/heat alarms
- Wireless communication
- Unique house-coding feature
- Visual RF transmission indicator
- Advanced suppression and test technology
- Radio transmitter in each unit
- Non-removable lithium battery
- 5 Year Guarantee (limited)

Product Description

The EIB411RF remote control is designed for use with the RadioLINK range of products. It increases the flexibility and user friendliness of the alarms by allowing the user to remotely "Locate", "Hush" and "Test" the alarms in the system.

- Locate the source of the alarm
- Hush any nuisance alarms
- Test alarm system
- Alarm memory identifies units that have previously alarmed (useful for troubleshooting)

The EIB411RF remote control is powered by a non-removable lithium battery designed to last the life of the product. The EIB411RF remote control uses advanced radio transmitter technology with unique software coding to transmit the radio signals, ensuring robust signal integrity.



Technical Specification

Control switches: Locate, Test & Hush

Power Supply: 10-year lithium battery

RF Visual Indicator:

Amber light flashes while transmitting an RF signal

RF Frequency: 926MHz band

RF Power: +5dBm

Dimensions: 88mm x 88mm x 42mm

Weight: 212g

Low Battery Indicator:

Amber light dim when a button is pressed and alarms fail to respond to "Test" signal

Temperature Range:

0° to 40°C

Humidity Range: 15% to 95% relative humidity

Interconnect: Up to 12 RadioLINK products

Guarantee: 5 year limited guarantee

Approvals: Conforms to AS/NZS4268

Compatibility

140RC Series fitted with EIB168RC
650i Series & EIB603TYC fitted with EIB600MRF
EIB603C & EIB605C fitted with EIB605MRF

Note: For full specification and limitation for use refer to the specific product data sheet

Due to continual product development, Brooks reserve the right to alter product details and specifications without prior notice.

Head Office: Sydney, 4 Pike Street, Rydalmere 2116 | PO Box 7050 Silverwater BC1811

Regional Offices: Melbourne - Brisbane - Adelaide - Perth - Auckland

www.brooks.com.au - Toll Free 1300 783 473