

# EIB450 - Alarm Controller

## RadioLINK

### Fire and CO (Carbon Monoxide)

#### Key Features

- Completely wireless
- Battery powered (>10 year life)
- One button - three functions
  - Test: Test alarms
  - Locate: Identify triggered alarms
  - Silence: Silence Alarms
- Alarm and Fault Indicators (icons)
  - Fire (smoke or heat detected)
  - CO (Carbon Monoxide detected)
  - EOL (End of Life detected)
- Diagnostic & Memory functions
- 5 Year Guarantee

#### Product Description

The EIB450 is powered for life (>10 years) intuitive remote controller for RadioLINK wireless Fire and CO (Carbon Monoxide) Alarm systems. It is completely wireless and can be wall mounted or free standing.

In standby the Alarm system can be easily tested by just pressing the button. This will test and sound all the Alarms.

When the system is activated the triggering Alarm can be identified (located) by simply pressing the button. Once identified it may then be silenced by pressing the button again.

The EIB450 will identify the triggering Alarm and indicate if it is a fire (smoke or heat) or CO (Carbon Monoxide) Alarm by flashing the appropriate icon.

An EOL (End of Life) icon will flash to indicate that the EIB450 has reached the end of its useful life (>10 Years).

The diagnostic mode allows an extended two minute test to be selected. It also allows a previously triggered Alarm to be identified, this is also known as the memory feature.

The EIB450 may be wall mounted or free standing to facilitate easy removal for walk round tests. In applications where security is an issue the EIB450 can be fixed to the wall mounting with two levels of tamper proofing to prevent unauthorised removal.



#### Technical Specification

Supply Voltage:	3V Lithium Battery - Powered for life
Battery Life:	> 10 years (normal operating conditions)
Communication:	926Mhz RadioLINK protocol
Fixing:	Wall mounting - fixtures supplied
Temperature:	Operating - 0 to 40°C Storage - 0 to 35°C (in a dry area)
Humidity Range:	15% to 95% Relative Humidity
Button functions:	Test - Test Alarms Locate - Identify triggered alarms Silence - Silence alarms
Indicators:	Fire - Illuminates when fire detected CO - Illuminates when CO detected EOL - Illuminates to indicate End Of Life
Memory:	Identifies previously triggered alarms
Diagnostics:	Walk round test Extended two minute test
Plastic material:	UL94HB
Dimensions:	Product - 90mm x 90mm x 30mm Package - 153mm x 153mm x 40mm
Weight:	185g (Incl. Pkg.)
Warranty:	5 year (limited) warranty
Approvals:	Conforms to AS/NZS 4268:2012



Due to continual product development, Brooks reserve the right to alter product details and specifications without prior notice.

**Head Office:** Sydney, 4 Pike Street, Rydalmere 2116 | PO Box 7050 Silverwater BC1811  
**Regional Offices:** Brisbane - Adelaide - Melbourne - Perth - New Zealand  
[www.brooks.com.au](http://www.brooks.com.au) - Toll Free 1300 783 473