

## Electronic Bell

B012CR	12VDC Red Bell 155mm
B012RWR	12VDC Weatherproof Red Bell 155mm
B024CR	24VDC Red Bell 155mm
B024RWR	24VDC Weatherproof Red Bell 155mm
B240AR	240VAC Red Bell 155mm
B240ARWR	240VAC Weatherproof Red Bell 155mm



A unique, patented alarm bell designed for use in fire, security and other signaling systems. The combination of a miniature solenoid with an integrated control circuit allows excellent sound coverage, minimum current consumption and increased reliability. The improved aesthetics make the bell suitable for all applications including the most prestigious locations.

### Features

- 155mm (6") gong
- High sound output
- Low current consumption
- Locking facility
- Simple installation
- No backbox required for surface wiring
- Weatherproof version available

### Technical Specification

<b>Voltage</b>	9-15VDC 18-30VDC 200-230VAC
<b>Current</b>	60mA (12VDC) 30mA (24VDC) 25mA (230VAC)
<b>Sound output</b>	93-95dB(A)
<b>Monitoring</b>	Reverse polarity (DC versions only)
<b>Temperature</b>	-25°C to +70°C
<b>Construction</b>	Gong – Steel Base – Polycarbonate
<b>Protection</b>	IP41 – Internal IP55 – External
<b>Weight</b>	1.1kg (DC) 1.2kg (AC)
<b>Colours</b>	Gong – Red or Grey Base - Black