

5054 Remote Display Unit



The 5054 is a coloured touch screen display used to distribute immediate and accurate information about the status of the building’s fire alarm system. The 5054 is extremely flexible with the ability to tailor the information sent to each device so the recipients only receive the information relevant to them.

The 5054 can be configured as an:

External presentation unit: Presents fire alarm information, general fault and general disablement. Suitable for Class 9C Building applications.

Alert Annunciation Unit: Provides opportunity to further reduce the risk for unwanted alarms transmitted to the fire brigade. The Alert Annunciation Unit presents alarm conditions and provides the opportunity to investigate the situation, acknowledge and cancel any unnecessary alarms programmed for Alert Annunciation.

Features

- Selectable Function as Presentation unit or Alert annunciation unit
- Colour Touch Screen 10.1”
- Resolution 1024 x 600 RGB
- Adjustable buzzer sound and display brightness
- Up to 30 Units can be connected to one EBL Control unit
- Up to 1200-meter distance to the unit farthest away from the FDCIE

Technical Specification

Voltage (V DC) Allowed	12-30
Ambient Temperature (C°)	- 5 to + 40
Operating Storage	- 40 to + 70
Ambient Humidity (% RH)	> 95, non-condensing
Ingress Protection Rating	IP 30
Size l x h x d (mm)	169 x 264 x 56
Weight (g)	1400
Color	Light Grey (NCS S 1500-N)

Compatibility

Device	Description
FT128V2	Single Loop Fire Tracker Analogue Addressable Fire Indicator Panel
FT1020G3	4 Loop Fire Tracker Analogue Addressable Fire Indicator Panel