


Fire Detectors

External Power Supply

Model 3366

- Connected to a COM loop
- Monitored from the c.i.e.
- Space for batteries inside the housing



General

The **Ext. power supply 3366** consists of a rectifier (the main power source) and a charger board mounted in a grey metal housing, which also has space for two maintenance-free sealed Lead-Acid backup batteries, rated 12 V, 6.5-7.5 Ah (the second power source). Larger batteries (up to 60 Ah) have to be placed outside the housing.

The unit is connected to a COM loop. It is monitored from the c.i.e. and e.g. loss of the main power source (230 V AC) will generate a fault in the c.i.e.

There are cable inlets on the top, bottom and back sides of the housing and two compression glands are attached.

Charging mode

Low current charging mode is used for batteries ≤ 27 Ah. 24 V DC output ≤ 2.2 A.

High current charging mode is used for batteries **28-60** Ah. 24 V DC output ≤ 0.85 A.

A fire alarm in the system will automatically turn off the battery charging, i.e. the output current can then be up to 4 A.

Inputs / Outputs / Connectors

All connections are done on screw terminals except for the batteries, which have tab terminals.

- Mains (230 V AC)

- Battery no. 1 (12 V, 7.5-60 Ah)
- Battery no. 2 (12 V, 7.5-60 Ah)
- 24 V DC output, 2.2 A alt. 0.85A (4 A)
- Earth connector
- /Mains OK output (Output designed for the 3364 unit.)
- COM loop (in)
- COM loop (out)

Settings

The COM loop address is set with an Address setting tool 3314. The unit has an address label where the address is to be written. 3314 is also used to set the mode:

NORMAL mode: This mode can be used in system **Firetracker 512** with S/W version ≥ 2.3 and in system **Firetracker 128**.

2330 mode: This mode is used in system **Firetracker 512** with S/W version $\leq 2.2.x$. The unit has to be programmed in Win512 as "SU4 Addressable 4 voltage outputs unit 2262 / 2263. The unit will in Win512 via "Check all loop units" be identified as an "SU4 Addressable 4 voltage outputs unit 2262 / 2263".

2312 mode: Not used for 3366.

Product applications

The 3366 unit is used in the **Firetracker 128** & 512. and is used when an external power supply monitored from the c.i.e. is required.



Panasonic


Fire System Technology

Australia Head Office: 4 Pike Street Rydalmere NSW 2116
Ph+61 2 9684 1466 **Fx**+61 2 9684 4146 **Toll Free** 1300 78 FIRE

New Zealand Unit 106, The Zone, 23 Edwin Street Mount Eden 1024
Ph+64 9 638 4644 **Fx**+64 9 6384645 **Toll Free** 0800 220 007

Web: www.brooks.com.au (Aus) www.brooks.co.nz (NZ)

Type number	
3366	External power supply (batteries are not included)



External power supply (3366) inside view: Rectifier 230 V AC / 24 V DC (1537), Charger board (3367) and space for two batteries rated 12 V / 6.5-7.5 Ah (size 150 x 65 x 94 mm).

JP2 open = **low current** charging mode. JP2 shunted = **high current** charging mode.

Jumper JP2 is situated on the charger board, see figure.

a) = four knock-outs 23.5 mm (on the top, bottom and back side respectively).

Technical data	
Voltage	
Primary (V AC)	230
secondary (V DC)	
normal	24
by battery backup	18 – 28
COM loop (V DC)	
normal	24
allowed	12 - 30
Current consumption from COM loop (mA)	
quiescent	≤ 15
active	≤ 15
Board 3367 current consumption (mA)	25 mA, by backup battery power supply
/Mains OK output	Normally low (Output designed for the 3364 unit.)
24 V output (A)	2.2 alt. 0.85 (Low alt. high current charging mode.) 4 (When no battery charging, i.e. fire alarm in the system.)
Batteries, 12 V (Ah)	
inside the housing	2 x Sealed Lead-Acid
outside the housing	6.5-7.5 (physical size 150 x 65 x 94 mm) ≤ 60 Ah NOTE! JP2 open or shunted depending on charging current mode.
Ambient temperature (°C)	
operating	0 to +40
storage	-20 to +70
Ambient humidity (% RH)	Max. 90, non condensing
Ingress Protection rating (estimated)	IP30
Weight (kg)	4.8 (excl. batteries)
Size H x W x D (mm)	288 x 400 x 95
Construction / Colour	Metal housing / Light grey (NCS S1500-N, PMS Cool Grey 2)
Approvals	AS7240.4 CE 05 EC Certificate no. 0845-CPD-232.1491; EN54-4

NOTE! All current consumptions are valid by 24 V DC (nominal voltage) at 25° C.



Panasonic

Fire System Technology

Australia Head Office: 4 Pike Street Rydalmere NSW 2116
Ph+61 2 9684 1466 **Fx**+61 2 9684 4146 **Toll Free** 1300 78 FIRE

New Zealand Unit 106, The Zone, 23 Edwin Street Mount Eden 1024
Ph+64 9 638 4644 **Fx**+64 9 6384645 **Toll Free** 0800 220 007

Web: www.brooks.com.au (Aus) www.brooks.co.nz (NZ)

E & OE As our policy is one of continuous product development, we reserve the right to alter product details without prior notice. DS3366 13/02/12

Sydney - Melbourne - Adelaide - Brisbane - Perth - Hobart - Darwin - New Zealand
fire products and solutions